

Davis Weather Wizard III



The most-requested features at an economical price. Basic model includes inside and outside temperature, wind speed and direction, and wind chill. With the complete station, you'll also get daily and accumulated rainfall.

All station include the following components:

- Console with reversible base for use on desk, shelf or wall.
- AC- power adapter with battery backup (battery not included)
- Quick and easy plug-in cable connections using modular RJ connectors like those found on your telephone.
- Anemometer with 40' (12m) cable for wind speed and direction
- Outside temperature sensor with 25' (7.6m cable)

Optional components include:



Rain Collector

Designed to meet the guidelines of the World Meteorological Organization, our self-emptying rain collector with tipping bucket is exceptionally accurate. Measures in 0.01" or 0.2mm increments.

Includes 40' (12 m) cable. Use Standard 4-Conductor Extension Cable. Maximum cable length is 900' (270 m) from rain collector to console including junction box cable.



Surge Protector

For upgraded protection against lightning-induced power surges, powercross conditions, and ground potential rises, use surge protectors with any of our cabled weather stations. See the chart for the number of protectors required for your installation. Stripping of wires is required.

NUMBER OF SURGE PROTECTORS REQUIRED

Weather Station	Cable Run	Number of Surge Protectors
Weather Wizard III	Temperature sensor to junction box	1
	Rain collector to junction box	1
	Anemometer to junction box	2
	Junction box to console	4

MODEL	DESCRIPTION
7425	Weather Wizard III
7425 CS	Complete Weather Wizard III with rain collector
Optional	
7852	Rain Collector
7767	Surge protector
7862	Weatherlink (Window version)
7866	Weatherlink (Mac)
7876-008	Cable, 8' (2.4m)
7876-040	Cable, 40' (12m)
7876-100	Cable, 100' (30m)
7876-200	Cable, 200' (60m)